



Voice Mail and Automated Attendant
Quick Reference Guide

Aspire IntraMail

NEC

Sending Calls to a Mailbox

- To forward your incoming calls to your mailbox** Press idle CALL key ● Dial *2 ● Dial Call Forwarding condition (2 = Busy or not answered, 4 = Immediate, 6 = Not answered) ● Press MSG ● Select type of calls to be forwarded (2 = All calls, 3 = Outside calls, 4 = Intercom calls) ● Hang up
- To cancel forwarding** Press idle CALL key ● Dial *20 ● Hang up
- To transfer an outside caller to a mailbox** Press HOLD ● Press MSG ● Call extension ● Hang up
(You can optionally call the extension before pressing MSG to transfer the call.)

An Additional Way to Call Your Mailbox (from Outside)

- To call your mailbox from outside** Dial the Automated Attendant number ● Wait for greeting ● Dial # and your mailbox number ● (Optional) Enter your Security Code
If this feature is not enabled in your system, see your System Administrator.

Additional Ways to Record a Message

- Quick Message from outside** Dial the Auto Attendant number ● Wait for greeting ● Dial * ● Dial extension ● Leave message ● Hang up
- After you call an extension** Press MSG



0893420

NEC
NEC Unified Solutions, Inc.
4 Forest Parkway, Shelton, CT 06484
TEL: 203-926-5400 FAX: 203-929-0535
www.necunifiedsolutions.com

November 18, 2004
Printed in U.S.A.

Voice Mail lets callers leave recorded messages for you and lets you leave recorded messages for co-workers. Messages get stored in each person's mailbox. To listen to your messages or use other Voice Mail features, you call your mailbox and access the Main Menu. **Your Message Wait LED flashes (red) when you have a new message.** **Automated Attendant** answers your company's calls with a recorded message and gives dialing instructions for callers to follow.

[Super Display Soft Key] - [Keyset Soft Key]

Main Menu

L Listen to Messages [Listen] - [Lstn] **5**

While listening you can:

RE	Record REply [Reply] - [N/A]	73
MF	Have Msg Forwarded [Forward] - [N/A]	63
MC	Make Call to Sender [Callback] - [N/A]	62
TI	Get Time, Date, [Sender]	84
SA	SAve Message	72
E	Erase Msg [Erase] - [Erase]	3

L	Listen to Next Msg [Next Message] - [Next]	5
B	Backup a Few Secs	2
BB	Backup to Beginning [Repeat] - [Rpt]	22
G	Go Ahead a Few Secs	4
*	Pause/Resume Listening [Pause] - [NA] [Resume] - [N/A]	*
IN	Select New Message List	16

1S	Select Saved Message List	17
1A	Select All Message List	12
#	Exit Listen Mode [Exit] - [Exit]	#
Select the Listen Mode [Message List] - [N/A]		
See also "Select Listen Mode" on the Main Menu		

RS Record & Send a Message [Record] - [Rec] **77**

Enter mailbox number, then:

*	Reenter mailbox number [Mailbox] - [MBOX]	*
#	Start Recording [Continue] - [Cont]	#
	Exit to Main Menu [Exit] - [Exit]	

While recording you can:

*	Pause/Resume [Pause] - [Pause] [Resume] - [Resume]	*
E	Erase Recording [Cancel] - [Cncl]	3
#	End Recording [Done] - [Done]	#

G Mailbox Greeting [Greeting] - [Greet] **4**

Callers hear your active greeting (1-3) only if you do not answer or are busy. If Auto Attendant DND is ON, the Auto Attendant does not ring your phone. Callers immediately hear your active greeting. If OFF, the Auto Attendant will try your extension.

RN Record Mailbox Name [Name] - [N/A] **76**

IntraMail will play your mailbox name in the voice prompts instead of your mailbox number.

OP Mailbox Options [MBOX Options] - [N/A] **67**

The mailbox options are as follows:

S	Security Code [Sec. Code] - [Sec] 7 Changes or erases your mailbox security code.
N	Message Notification [Notification] - [Notif] 6 Calls co-worker or outside number when you get msg.
AT	Auto Time Stamp [Time Stamp] - [Time] 28 Plays the msg time, date and sender after the msg.
#	Exit Menu [Exit] - [Exit] #

TI Time and Date **84**

SA Sys Admin Options (For Admin Mailboxes only) [System Admin] - [N/A] **72**

	Select Listen Mode [Message List] - [N/A]	
1N	Select New Message List [New Messages] - [N/A]	16
1S	Select Saved Message List [Saved Messages] - [N/A]	17
1A	Select All Message List [All Messages] - [N/A]	12
These options are also available while listening to a message.		

X EXit Mailbox [EXIT] - [EXIT] **9**

Calling Your Mailbox and Accessing the Main Menu

To call your mailbox from outside the company:

1. Dial company phone number _____.
2. Wait for the Automated Attendant to answer.
3. Dial # and your mailbox number.
 - Optionally dial * and a co-worker's mailbox number to leave them a message.
 - The codes in your system may be different.

To call your mailbox from your extension:

1. Press MSG.
 - From a single line extension, lift handset and dial *8 instead.

To access a feature from your mailbox's Main Menu:

1. Dial the letters shown to the left of the feature name.
 - The corresponding numbers are shown to the right.
 - The letters you dial match some of the letters in the feature name.
 - To get a recorded help message, press 0.